



TECHNICAL SERVICE BULLETIN

PARTS & SERVICE DEPARTMENT

300 Maddox Simpson Pkwy
Lebanon, Tennessee 37090
615-889-8900 Fax: 615-547-1003
www.Lochinvar.com

Date: June 18, 2008

Bulletin Number: 2008-04T

TO: Manufacturers' Representatives, District Sales Managers, Regional Managers, Technical & Customer Service Personnel, Service Agents and Sales & Marketing Personnel

SUBJECT: Knight Boiler ASME Data Plate Location

We have recently had several inquiries into the location of the ASME data plate and the model/serial number courtesy sticker on the Knight product family and the best way to view both. Listed below are the steps needed to locate the ASME data plate and courtesy sticker.

To locate the ASME data plate on the Knight 80,000 BTU/hr thru 285,000 BTU/hr and the Knight XL 399,000 BTU/hr thru 800,000 BTU/hr models, remove the front and top panel from the boiler. Once the panels are removed, locate the rear header on the right side of the heat exchanger. The ASME data plate will be directly behind the automatic air vent. For models 285,000 btu/hr thru 800,000 btu/hr, it will be necessary to pull back the insulation until the ASME plate is visible.

To locate the courtesy sticker on the Knight 80,000 btu/hr thru 285,000btu/hr models, remove the front panel from the boiler. Once the front panel has been removed, look to the upper right hand corner. In the corner there will be a grey sticker that will have the model, serial, and control number of the boiler.

For the Knight XL 399,000 BTU/hr thru 800,000 BTU/hr models, the courtesy sticker will be located on the outside of the unit. On the left side of the boiler, there will be a grey sticker that will have the model, serial, and control number of the boiler.

To locate the ASME data plate on the Knight Wall Mount 50,000 btu/hr thru 210,000 btu/hr models, remove the front panel. Once the panel is removed, locate the rear header on the right side of the heat exchanger. The ASME data plate will be directly behind the automatic air vent.

To locate the courtesy sticker for the Knight Wall Mount 50,000 btu/hr thru 210,000 btu/hr models, remove the front panel of the boiler. Once the front panel has been removed, look to the upper left hand corner. In the corner there will be a grey sticker that will have the model, serial, and control number of the boiler.